

Model Specification Clause:

1. Supplier:

The Rooflight Company,
Unit 8, Wychwood Business Centre
Milton Road, Shipton-under-Wychwood
Oxfordshire OX7 6XU

Telephone: 01993-830613

Fax: 01993-831066

Email: info@therooflightcompany.co.uk

Refer to quotation ref: _____

Name of contact: _____

2. Rooflight type/Location:

Window/Rooflight number:	The Rooflight Company model reference:	Ironmongery & other options:
RL1	CR-1	<ul style="list-style-type: none">• Thermoliner.• Option C opener.• 4mm Toughened Low E inner, 12mm air gap, 4mm Toughened Outer DGU• Colour: dark grey (BS 00A13)• Eclipse blind in cream colour
RL2	CR-9	<ul style="list-style-type: none">• Thermoliner.• Option C opener.• 4mm Toughened Low E inner, 12mm air gap, 4mm Toughened Outer DGU• Colour: dark grey (BS 00A13)• Eclipse blind in cream colour
RL3	CR-9	<ul style="list-style-type: none">• Thermoliner.• Option C opener.• 4mm Toughened Low E inner, 12mm air gap, 4mm Toughened Outer DGU• Colour: dark grey (BS 00A13)• Eclipse blind in cream colour
RL4	Pyramid 600	<ul style="list-style-type: none">• Option G winding crank• Colour: dark grey (BS 00A13)

Installation and Workmanship:

- a. Supply and fix rooflight assemblies to positions noted on plans and in accordance with the above schedule (**The Rooflight Company SUPPLY ONLY**). Standard abutment details as follows:

- For RL___ and RL___ use The Rooflight Company detail set for _____ tile abutments (copy appended).

Use Code _____ lead to cill and for soakers to jambs. Clip leadwork at rooflight cill at _____ centres in accordance with the recommendations contained within The Lead Sheet Manual Volume 1, page 8.

- a. Advise site architect/surveyor of any proposed variation to The Rooflight Company details before the rooflights are installed.
- b. Supply and fix all trimmers packers fillets bearers and linings as necessary and as shown on the details or implied thereby.
- c. Install and commission ironmongery, and blinds where specified. Clean all rooflights and leave in good working order.
- d. Keep in neat and clean order and upon completion of installation give rooflight manufacturer installation/maintenance instructions to site architect/surveyor or client/building owner for incorporation into a building maintenance manual.
- e. Protect and keep any ironmongery items such as pole cranks or cleaning tools until completion of installation, whereupon give these items to the site architect/surveyor or client/building owner.

Add the following clauses where appropriate.

- f. All lead sheet to be to BS En 12588:1999 with Workmanship (for fully supported roof leadwork) to BS 6915:1988. All flashings to be detailed as recommended in The Lead Sheet Manual Volume 1, obtainable from the Lead Development Association.
- g. All roof tiling to be laid in accordance with BS 5534 Part 1 and 2 Code of Practice for slating and tiling, and BS 8000 Part 6 Code of Practice for Workmanship on building sites for roof, slate and tile coverings and claddings.